

Instructions of drilling holes for hinges

1. Drill the hole for the body of the hinge 12mm deep but no deeper.
2. When screwing the hinge to the door first of all make a pilot hole of 3.0mm prior to putting the screw in.

We suggest that this be done by hand as when it is done mechanically it can make the hole too deep

Similarly putting the screw in is best done by hand.

3. Use a 3/8 x 8 wood screw to attach the hinge to the door. 3/8 inch is the optimum size. 1/2 inch may be used but certainly not 5/8
4. The number of hinges to be used is suggested as follows:

Up to 710mm high x 600mm wide - 2 No

Up to 1000mm high x 600mm wide – 3 No

Up to 1330mm high x 600mm wide – 4 No

Up to 1670mm high x 60mm wide – 6 No